







MOS GB 1124-1
NIBE™ F205P
031977

INSTALLATION AND MAINTENANCE INSTRUCTIONS

NIBE™ F205P

1 x 230 V UK





For home Owners


General	2
System description	3
System diagram	3
Principle of operation	3
Front panel	4
Functions on the front panel	4
Front panel, supplied clock thermostat	5
Front panel's functions	5
Settings	6
Maintenance routines	7
General	7
Cleaning the air filter	7
Cleaning the ventilation devices	8
Pressure gauge	8
Checking the safety valves	8
Dealing with malfunctions	9
Low temperature or a lack of hot water	9
Low or a lack of ventilation	9
Low room temperature	9
High room temperature	9
Switch position "3"	9
Cleaning the fan	9
Indications on the display	10
Lamp "Compressor is operational/alarm" is flashing	10
Lamp "Defrosting is operational/check filter" is flashing	10
Lamp "Defrosting is operational/check filter" is litted	10
Resetting the pressostats	10

For the Installer

General information for the installer	11
Transport and storage	11
Handling	11
Installation	11
Hard water areas	11
Inspection of the installation	11
Maximum boiler and radiator volumes	11
Installing the clock thermostat	12
Pipe connections	13
General	13
Pump and pressure drop diagram	14
Cleaning the system	14

Tap water connection	14
Ventilation connection	15
Ventilation flow	15
Kitchen duct	15
Adjustment	15
Fan diagram	15
Duct installation	15
Electrical connections	16
Connection	16
Setting the fan capacity	16
Connecting fan switch	16
Circulation pump control	17
Current, fuse	17
Immersion heater	17
Connecting the clock thermostat	17
Commissioning and adjusting	18
Preparations	18
Venting the heating system	18
Temperature levels	20
Hot water temp.	20
Periodic increase	20
Hot water prioritising	20
Service	21
Electrical circuit diagram	26
List of components	29
Dimensions	30
Dimensions and setting-out coordinates	30
Enclosed kit	31
Accessories	31
Technical Data	32
Benchmark checklist	34

System description



Principle of operation

F205P comprises an electric boiler with a stainless steel water heater and a heat pump which recovers energy from the ventilation air. The recovered energy is supplied to the heat pump. The heat pump must be installed in a ventilation system intended for mechanical exhaust air. A DC fan is used in F205P.

The output of the immersion heater is 3 kW. When the exhaust air at room temperature passes through the evaporator, the refrigerant evaporates because of its low boiling point. In this way the heat in the air is transferred to the refrigerant.

The refrigerant is then compressed in a compressor, causing the temperature to rise considerably.

The warm refrigerant is led to the condenser. Here the refrigerant gives off its heat to the boiler water, so that the temperature of the the refrigerant drops and its phases changes from gas to liquid. The refrigerant then goes via a filter to the expansion valve, where the pressure drops and the temperature is lowered further.

The refrigerant has now completed its circulation and returns to the evaporator.

System diagram

C

When the room air has passed through the heat pump it is discharged. The temperature of the air has been significantly reduced as the heat pump has extracted the energy in the room air.

G


The air from the kitchen fan goes directly out into a separate duct.

A

The warm room air is drawn into the air duct system.

F

Air is transported from rooms with outdoor air devices to rooms with exhaust air devices.



B

The warm room air is fed to F205P


D

F205P supplies the house with both hot water and room heating.

E

Outdoor air is drawn into the house.

Front panel



Functions on the front panel

A Thermometer
Here the boiler temperature is indicated. The value depends on the cut-out temperature of the immersion heater, the set value for the compressor cut-out temperature and the hot water taps.

B Pressure gauge
Here the pressure of the radiator circuit is indicated. The scale marks go from 0 - 4 bars. Normal pressure is 0,5 - 1,5 bar.

C Indicators lamps

Top lamp	
Lit	Compressor is running.
Flashing	Alarming for tripped pressostates or indicating standby mode (Compressor blocked).
Not lit	Compressor is not running.
Midmost lamp	
Lit	Defrosting is operational.
Flashing	Air filter to be cleaned.
Not lit	-
Lower lamp	
Lit	Immersion heater is in operation.
Flashing	-
Not lit	Immersion heater is not in operation.

D Switch
with 4 positions 0 - 1 - 2 - 3:

- 0 Heat pump off.
- 1 Fan is operational. Compressor and circulation pump operational on demand.
- 2 Fan is operational. Compressor, immersion heater and circulation pump operational on demand.
- 3 Standby mode. Fan is operational. Compressor is not operational. Immersion heater and circulation pump operational on demand.


E Hot water prioritising (hidden)
with 3 positions "Auto" - "1" - "0":

Auto	Hot water prioritising continuously activated (same function as "1")
1	Hot water prioritising continuously activated.
0	Hot water prioritising not activated.

F Circulation pump (hidden)
with 2 positions "Auto" - "1":

Auto	The circulation pump is controlled on and off by the control system or clock thermostat.
1	Circulation pump in continuous operation.

Front panel, supplied clock thermostat



Front panel's functions

The indoor temperature is regulated using a room thermostat. When the temperature in the accommodation is the same as the temperature set on the room thermostat, the circulation pump in the heat pump stops.

To set different intervals with a temperature change, we recommend the supplied clock thermostat. For instructions on how to set times and temperatures, see section "Settings".

- A Display**
 First row: Week day.
 Second row: Operating mode day ☀, operating mode auto ⊖, heating on ☸.
 Third row: Actual indoor temperature (RT) or set indoor temperature (SET), clock
 Fourth row: Actual fan speed, operating mode night ☾.
- B On/Off**
 Press "⏻" once to switch off the thermostat, press again to restart.
- C Operating mode**
 The operating mode that the heat pump is to use is selected here.
 Auto ⊖: In this mode the heat pump operates according to your own settings. You set which temperature you want indoors during day and night.
 Day ☀: In this mode you get the setting for day temperature for the entire day.
 Night ☾: In this mode you get the setting for night temperature for the entire day.
 Manual: (no symbol) In this mode the set temperatures are not used. Press Δ or ▽ to increase or decrease the temperature indoors.
- D Timer**
 Set current time and date here.
- E Fan speed**
 Select the fan speed here: high ☸, normal ☷ and auto (no symbol).
 If normal ☷ or high ☸ is selected, you return to the previous setting after one hour.
 If normal ☷ or auto is selected, the fan runs at low speed when the compressor has stopped and rotates up to speed when the compressor is in operation.
- F Increase/decrease**
 These buttons are used to increase or decrease a value.

Settings


Set actual time and weekday

1. Press the timer button once \ominus . The first two digits in the clock start to flash.
2. Use Δ or ∇ to set the hours. Save the settings by pressing the timer button once.
3. Use Δ or ∇ to set the minutes. Save the settings by pressing the timer button once.
4. Use Δ or ∇ to set the weekday. Save the settings by pressing the timer button once.

Changing the indoor temperature

A water borne heating system has a certain inertia. This means that it can take several hours from when the change was made until the desired temperature in the accommodation is achieved. The size of the house, outdoor temperature, hot water usage during the time etc. affects how long the change takes.

E.g. You change the 05:00 setting of the clock thermostat from 17 °C to 20°C. F205P starts to increase the tempera-



ture but it can take several hours for the heat pump to achieve the desired change.

At 08:00 you change the setting again, from 20 °C to 17°C. The heat pump then starts to send out cooler water to the heating system but it can take several hours before the water has cooled enough to achieve the desired temperature.

Programme operating mode

Start by making settings for Monday to Friday:

SET 1 means period 1, SET 2 means period 2.

1. Hold in the timer button \ominus until SET 1 appears in the display.
2. Set the time at which you want period 1 to start to apply. Set the time in the same way as you set the clock previously, using Δ or ∇ and the timer button.
3. Set the temperature you want indoors during period 1 by pressing Δ or ∇ . Save the settings by pressing the timer button once.
4. Set the time at which you want the period 1 setting to stop being applied. Set the time in the same way as you set the clock previously, using Δ or ∇ and the timer button.
5. Set the temperature you want indoors between peri-

ods 1 and 2 by pressing Δ or ∇ . Save the settings by pressing the timer button once.

6. SET 2 now appears in the display. Set the time at which you want period 2 to start to apply. Set the time in the same way as you set the clock previously, using Δ or ∇ and the timer button. The temperature will be the same as you selected in period 1.
7. Set the time at which you want the period 2 setting to stop being applied. Set the time in the same way as you set the clock previously, using Δ or ∇ and the timer button.

Now make settings for Saturday and Sunday:

1. This is done in the same way as setting the temperatures for weekdays (repeat steps 2-7).


Change operating mode

Press operating mode button (M) to switch between auto, day, night and manual mode. Confirm using the timer button \ominus .

If you want one indoor temperature during the daytime and another indoor temperature during the night select operating mode auto \odot .

If you want the day temperature for 24 hours select \odot and if you want the night temperature for 24 hours select \circlearrowleft .

To change temperature at any point during the day, select the manual mode. If the temperature in the accommodation is too low or too high, press Δ or ∇ to increase or decrease the temperature. Approximately 30 seconds after the last button push, the thermostat returns to showing the actual room temperature.



Maintenance routines

General

The heat pump and its ventilation ducting require some regular maintenance when the following points should be checked.



The numbers in brackets refer to the section "Component locations".

Cleaning the air filter


The heat pump air filter (63) should be cleaned regularly, about four times a year.

1. Set the switch (8) to "0".
2. The upper service cover is opened by pulling the lower section outwards. The cover can then be lifted off.
3. Pull out the filter cassette (78).
4. Take out the filter and shake/vacuum off any dirt. Do not use water or other liquids for cleaning.
5. Check that the filter is not damaged. New original filters can be ordered from a Nibe distributor.
6. Re-assembly takes place in the reverse order.

The cleaning time intervals vary depending on the amount of dust in the exhaust air. Each third month an indicator lamp "Midmost lamp" flashing to reminds about cleaning the air filter. Note that the time will be set to zero by setting the switch to "0".



Cleaning the ventilation devices




The building's ventilation devices should be cleaned regularly with a small brush to keep the correct ventilation.

The device settings must not be changed.

Note! If you take down more than one ventilation device for cleaning, do not mix them up.

Check that the ventilation opening (84), behind the lower front cover, is not blocked. Clean if necessary.

Pressure gauge



The pressure gauge shows the pressure in the heating system. The pressure should be between 0.5 and 1.5 bar.

Checking the safety valves


F205P has three safety valves, one for the heating system and two for the water heater.

The heating system safety valve (52) must be completely tight, but the hot water safety valve (47) may release some water after hot water has been used. This is because the cold water which enters the water heater to replace the hot water expands when heated, causing the pressure to rise and the safety valve to open.

Safety valve (104) does not normally release water.

The safety valves must be checked regularly. Check one valve at a time as follows:

1. Open the valve.
2. Check that water flows through the valve.
3. Close the valve.
4. The heating system may need to be refilled after checking the safety valve (52), see the section "Commissioning and adjustment" – "Filling the heating system".



In the event of malfunction or operating disturbances first check the points below:

Dealing with malfunctions

Low temperature or a lack of hot water

- Large amounts of hot water were used.
- Circuit or main MCB tripped.
- Possible earth circuit-breaker tripped.
- Wrong mode chosen on power switch (8).
- Temperature limiter (6) tripped. Contact service.
- Thermostat (3) for immersion heater set too low.

Low or a lack of ventilation

- Defrost mode - lamp flashing - see chapter "Lamp indications".
- Filter (63) clogged (possible replace).
- Exhaust air device blocked or throttled down too much.
- Circuit or main MCB tripped.
- RCD (if fitted) tripped.
- Setting of the manual fan switch (if mounted) is incorrect.


Low room temperature

- Circuit or main MCB tripped.
- Possible earth circuit-breaker tripped.
- Tripped temperature limiter (6). Contact service
- Incorrectly set value on the room thermostat.
- Circulation pump (16) stopped. See the section "Dealing with malfunctions" – "Starting the pump".
- Air in the boiler or system.
- Close valves (44) and (50) in the radiator circuits.
- Too low pre-pressure in the expansion vessel, contact the installer.

High room temperature

- Clock thermostat setting not correct

Switch position 3



When the switch is set to "3", the compressor is not operational. The fan and the immersion heater are operational. Normally the immersion heater lamp is lit in mode "3", when the immersion heater is operational.

A possible fault on the printed circuit card can cause the disappearance of the number display. However, the immersion heater is still operational, if the thermostat has not cut-out the immersion heater.


Cleaning the fan

The fan needs to be cleaned, if it is noisy. Call your installation engineer.

Note!

*In all correspondence with NIBE
state the serial number*

Indications on the display



Lamp "Compressor is operational/alarm" is flashing

- A fault has occurred in the cooling circuit. (One of the pressostats has cut-out).
- Mode "3" is set.

When the cause of the fault has been put right, the fault code must be cleared from the display by switching the heat pump off and on again.

Lamp "Defrosting is operational/check filter" is flashing


Air filter has to be cleaned (lamp flashing each third month). After cleaning the filter, the fault code must be cleared from the display by switching the heat pump off and on again.

Lamp "Defrosting is operational/check filter" is litted

When there is too much ice on the evaporator, defrosting takes place. After this, the compressor starts automatically if heating is needed. Frequent defrosting is a sign of clogged ventilation devices or dirty filters.

See "Maintenance routines" – "Cleaning air filters".

Resetting the pressostats



Low pressure pressostat. Normally this pressostat resets automatically, so it does not have a resetbutton.

To reset a tripped pressostat, press the button on top of it; see figure. The pressostats are within reach by opening the filter box.



Note!

*In all correspondence with NIBE
state the serial number*

General information for the installer

Transport and storage

The heat pump should be transported and stored vertically in the dry. The F205P may however be carefully laid on its back when being moved into a building.



Handling



The heat pump contains highly inflammable refrigerant. Special care should be exercised during handling, installation, service, cleaning and scrapping to avoid damage to the refrigerant system and in doing so reduce the risk of leakage.

Installation

The heat pump should preferably be erected with its back about 10 mm from an outside wall in a utility room or similar, to minimise noise nuisance. If this is not possible, avoid placing it against a wall behind a bedroom or other room where noise may be a problem. Irrespective of the placement the wall should be sound insulated. **NOTE!** The distance between the heat pump and the wall should be at least 10 mm.

Route pipes so they are not fixed to an internal wall that backs on to a bedroom or living room.

An area of approximately 15 cm is required on the left side of the heat pump, at the temperature and pressure valve (104) to enable access to the valve.

Note!

Since a waterfilled F205P weighs roughly 435 kilos, the floor must stand such a weight.

Hard water areas


Normally it is no problem to install F205P in hard water areas since the maxing working temperature is 60 °C.

Inspection of the installation

Current regulations require the heating installation to be inspected before it is commissioned. The inspection must be carried out by a suitably qualified person. The above applies to installations with a closed expansion vessel. A new inspection must be made when changing the heat pump or the expansion vessel.

Maximum boiler and radiator volumes

The volume of the expansion vessel (85) is 12 litres and it is pressurised as standard to 0.5 bar (5 mwp). As a result, the maximum permitted height "H" between the vessel and the highest radiator is 5 metres; see figure. If the standard initial pressure in the pressure vessel is not high enough it can be increased by adding air via the valve in the expansion vessel. The initial pressure of the expansion vessel must be stated in the inspection document.




Any change in the initial pressure affects the ability of the expansion vessel to handle the expansion of the water. The maximum system volume excluding the boiler is 106 litres at the above initial pressure.

Installing the clock thermostat


Installing the clock thermostat




Open the main control panel. Put the screwdriver (3.5mm) into the block 4mm along the bevel. Prize up, open the clips.



Take off the wires.



As per wiring diagram, connect it with terminals, fixed by the screwdriver.



Put the connected thermostat onto the back panel in the wall, then fix it with the two screws in the packing box.



Put the cover with 30 degree angle, then fix the up two clips;

Push the places of the two down clips, fix the cover, and finish the installation.

Note!

Be sure to connect all the wires as per the wiring diagrams and keep it away from water, mud and other material so as to prevent the unit being spoiled!

Pipe connections

General

This installation is subject to building regulation approval, notify the Local Authority of intention to install.

Use only replacement parts recommended by the manufacturer.

Pipe installation must be carried out in accordance with current norms and directives.

All domestic hot water circuits, connections and fittings must be in accordance with the relevant standards and water supply regulations. It should also be in accordance with the relevant requirements of the Local Authority and the Building Regulations relevant to the location of installation.

BS 6700 Services supplying water for domestic use within buildings and their cartilages.

Water Supply (Water Fitting) Regulations 1999 or The Water Bylaws 2000 (Scotland).

The installation of the heat pump should follow best practice as covered in the following:

BS 5449 Forced circulation hot water central heating systems for domestic premises.

BS 15450 Heating systems in buildings – Design of heat pump heating systems.

The system requires a low-temperature dimensioning of the radiator circuit. At DUT, the highest recommended

temperatures are 55 °C on the flow line and 45 °C on the return line.


When the circulation pump is running, the flow in the radiator circuit must not be completely stopped. When connecting to a system with thermostats on all radiators, a relief valve must be fitted, or some of the thermostats must be removed to ensure sufficient flow.

The total volume is 240 litres, with 170 litres in the water heater and 70 litres in the boiler section.

The pressure vessel in the F205P is approved for max 9.0 bar (0.9 MPa) in the water heater and 2.5 bar (0.25 MPa) in the double shell section.

Overflow water from the evaporator collection tray and safety valves goes via non-pressurised collecting pipes to a drain so that hot water splashes cannot cause injury. The outlet of the overflow pipe should be visible and clearly away from any electrical components. Likewise should the discharge pipes (tundishes), drain valves and motorised valves be positioned clearly away from any electrical components. These non-pressurised collecting pipes shall not be used for anything else. A discharge pipe from the tundish (108) connected to the expansion relief valve (47) (safety valve) shall also be connected to a drain in the same way.

No valve should be fitted between the pressure reduction valve (expansion valve) and the storage cylinder.



Note!

Do not use collection funnel (99) to discharge pipes from tundish (109).

Note!

This installation is subject to building regulation approval, notify the local Authority of intention to install.

Note!

Use only manufacturer's recommended replacement parts.

Table sizing of copper discharge pipe for common temperature relief valve outlet sizes.

Valve outlet size	Minimum size of discharge pipe	Minimum size of discharge pipe from tundish	Maximum resistance allowed, expressed as a length of straight pipe (i.e. no elbows or bends)	Resistance created by each elbow or bend
G1/2	15 mm	22 mm	up to 9 m	0,8 m
G1/2	15 mm	28 mm	up to 18 m	1,0 m
G1/2	15 mm	35 mm	up to 27 m	1,4 m
<G3>/4	22 mm	28 mm	up to 9 m	1,0 m
<G3>/4	22 mm	35 mm	up to 18 m	1,4 m
<G3>/4	22 mm	42 mm	up to 27 m	1,7 m
G1	28 mm	35 mm	up to 9 m	1,4 m
G1	28 mm	42 mm	up to 18 m	1,7 m
G1	28 mm	54 mm	up to 27 m	2,3 m

Cleaning the system / Flushing out of the hot water and the heating system

The pipe work must be flushed before the heat pump is connected, so that any contaminants do not damage the components parts.

After flushing, an inhibitor should be used for long term corrosion protection. Ensure all cleanser is removed from the system before adding the inhibitor.

NIBE Energy Systems Limited recommends Fernox and Sentinel water treatment products for heating and cooling systems.

Tap water connection

Hot and cold water are connected to pos (74) (hot water) and (73) (cold water).

The enclosed expansion vessel (107) must be connected to the hot water system.


The heat pump should be supplemented with an electric water heater if a bubble pool or other significant consumer of hot water is installed.

Setting the pump speed



To set the correct flow in the heating system, the correct speed must be set for the circulation pump in the different operating conditions.

Compare the planned heating with the available capacity for the circulation pump (16) and set the lowest possible pump speed.

You set the speed for the circulation pump with the help of the switch on the pump. Choose speed I, II or III. You can see the chosen speed to the left, above the switch. The display to the right, above the switch, should not be lit.



Pump and pressure drop diagram



Ventilation connection

Ventilation flow

Ventilation system should be installed and commissioned in accordance with the UK Building Regulations Part F England and Wales and Chapter 3.4, Scotland.

F205P is connected so that all ventilation air except the kitchen fan passes the evaporator (62) in the heat pump. For optimum heat pump performance the ventilation flow must not be less than 100 m³/h (28 l/s) when the compressor is in operation. F205P is equipped with a ventilation opening in the base. As a result, an air flow of about 5 m³/h.

(1,4 l/s) is taken directly from the room where the heat pump is installed. Changing the ventilation capacity is described under "Electrical connection - Setting the fan capacity". The curve's designation refers to the position of the knobs R51 and R52 on the circuit board (34).

Connect the supplied clock thermostat to select between normal or high ventilation.

Kitchen duct

Duct from Cooker Hoods must not be connected to the F205P.

Adjustment

To obtain the necessary air exchange in every room of the house, the exhaust air devices must be correctly positioned and adjusted. An incorrect ventilation installation may lead to reduced heat pump efficiency and thus poorer operating economy, and may result in damage to the house.

Fan diagram

The diagram below shows the available ventilation capacity.

Duct installation


To prevent fan noise being transferred to the exhaust air devices, it may be a good idea to install a silencer in the duct. This is especially important if there are exhaust air devices in bedrooms. Because the heat pump contains a flammable refrigerant in the form of propane (R290), the air ducting system must be earthed. This is done by making a sound electrical connection to the exhaust air duct and extract air duct using the two earthing cables supplied. The cables must then be connected to the earthing studs on top of the top cover.

Duct connections should be made via flexible hoses, which must be installed so that they are easy to replace. The extract air duct is to be insulated using diffusion-proof material along its entire length. Provision must be made for inspection of the duct. The exhaust air duct should be fitted with an adjustment damper. Make sure that there are no reductions of cross-sectional area in the form of creases, tight bends etc, since this will reduce the ventilation capacity. All joins in the ducting must be sealed and pop-rieveted to prevent leakage.

The air duct system should, at a minimum, be of air tightness class B.

Note!

A duct in a masonry chimney stack must not be used for extract air.



Electrical connections

Connection

The heat pump must be permanently connected to a 230V ac 50Hz supply.

All system components shall be of an approved type and all wiring to current I.E.E wiring regulations.

External wiring must be correctly earthed, polarised and in accordance with the relevant standards: Currently this is BS 7671.

Note!

The switch (8) must not be moved from "0" until the boiler has been filled with water. Otherwise the temperature limiter, thermostat, compressor and the immersion heater can be damaged.

Disconnect the heat pump before insulation testing the house wiring.

The supply (230 V~ 1-phase + N) for the heat pump must be connected to terminal (9) via a cable clamp.

The connection of the heat pump must be done under the supervision of a qualified electrician.

The heat pump installation implies a contact breaker.

The vinyl-pipe on the right side may be used as cable entry conduit.

The temperature limiter (6) cuts off the supply to the immersion heater if the temperature rises to 88 °C; it can be manually reset by pressing the button on the temperature limiter.

The temperature limiter (7) for the compressor cuts off the supply to the compressor if the temperature rises to 88 °C; it can be manually reset by pressing the button on the temperature limiter.

Note!

Reset the temperature limiters, it may have tripped during transport.

Note!

The electrical installation, wiring and any service work must be done in strict conformity to current regulations under the supervision of a qualified electrician.


Setting the fan capacity

Select the ventilation capacity by turning the knob on the circuit board (34) to the desired setting. See the illustration "Ventilation connection" – "Fan diagram".

The positions are as follows:

Knob R51: High ventilation, compressor in operation.

Knob R52: Normal ventilation, compressor stopped.




Connecting fan switch

Connect the supplied clock thermostat to select between normal or high ventilation.

Closing function between "8" and "9" means normal fan speed.

Closing function between "9" and "10" means high fan speed.

Connect the fan switch according to the image below.



Circulation pump control

Normally a room thermostat is used controlling the starts and stops of the circulation pump. When the set room temperature is reached, the circulation pump is stopped and starts again when the temperature drops. For connection see diagram "Electrical connections" – "Connecting the room thermostat".

The circulation pump can even be operated manually. No room thermostat will be connected. Instead the circulation pump is operated by the switch (18) on the front panel. The mode "Auto" does not permit any operation of the circulation pump if no room thermostat is connected. The switch in position "On" permits permanent operation of the circulation pump.

Current, fuse

The maximum current is 16,7 Ampere. Therefore a 20 Ampere fuse shall be used. NOTE! Relevant electrical standards must be considered.

Immersion heater


F205P is delivered with a 3 kW immersion heater (1). It is started and stopped via the microprocessor card (34). If a failure occurs there is a temperature limiter (6) (thermal cut-out) that is stopping the immersion heater. An immersion heater without a temperature limiter is not allowed to be mounted.

Connecting the clock thermostat for the circulation pump

Connect the supplied clock thermostat to terminal block (9) and (11) according to the image below.

Set switch, circulation pump (18) to "auto".

Set the clock thermostat according to the "Settings" sections.



Clock thermostat

Commissioning and adjusting

Preparations

When connecting to a system with thermostats on all radiators, a relief valve must be fitted, or some of the thermostats must be removed to ensure sufficient flow.

Check that the switch (8) is set to "0".

Check that valves (44) and (50) are fully open and that the temperature limiter (6) has not tripped (press firmly the knob). F205P is supplied with a limiting valve (5) mounted on the outlet pipe. This one allows to set a maximum outlet temperature in order to protect the floor in an existing floor heating system. This valve is adjustable between 36 and 60 °C. Factory setting is 38 °C which corresponds to a value between 1 and 2 on the knob. To change this value, remove the protective cover and turn the settings knob (19) clockwise for a lower temperature and anticlockwise for a higher temperature to the desired setting.

Filling the water heater and the heating system

1. The water heater is filled by opening a hot water tap. When water comes out of the hot water tap this can be closed.
2. Connect enclosed flexible hose (147) between connection (149) and connection (150) (the hose is mounted at the unit when this is delivered). Open filling valves (151) and (49). The boiler part of the heat pump and the radiator system are now filled with water.


3. After a while the pressure gauge (42) will show rising pressure. When the pressure reaches 2.5 (bar) (approx. 25 mvp) a mixture of air and water starts to emerge from the safety valve (52). The filling valves (151) and (49) are then closed.
4. Turn the safety valve (52) until the boiler pressure reaches the normal working range (0.5 - 1.5 bar).
5. The flexible hose between connection (149) and connection (150) must not be connected during operation. Therefore, remove it before the heat pump is started.

Note!

When filling, after the heat pump is started, the flexible hose must be installed between connection (149) and (150).

Venting the heating system

- Vent the electric boiler through the safety valve (52) and the rest of the heating system through the relevant venting valves.
- Keep topping up and venting until all air has been removed and the pressure is correct.



Starting

- Set the switch (8) to "2" in order to accelerate the heating of the radiator system. NOTE! The compressor has a start delay of about 10 minutes in the start mode.
- Set the designed capacity on the circulation pump using its switch (35). See the section "Pipe connections" – "Pump and pressure drop diagram". Make sure that the switch is not in an intermediate position.

Setting the ventilation

The ventilation flow and setting are given on the ventilation drawing. See section "Ventilation connection", "Fan diagram".

1. Remove any switches for ventilation changes from terminal block (11), pos 8-10.
2. Ensure that the heat pump's boiler section is filled with water.
3. Make sure that all outdoor air devices are fully open.
4. Adjust the normal ventilation speed using knob R52.
5. Start the heat pump with compressor operation. The compressor can be quick-started by pressing in button S202 on the circuit board (34).
6. Adjust the high fan capacity using knob R51. To ensure the lowest possible noise level, adjust the fan to the lowest possible capacity.
7. Set correct ventilation flows on the house exhaust air valves.
8. Reinstall any switches for ventilation changes in terminal block (11).

The ventilation flow must never be lower than 100 m³/h.

Readjustment

During the initial running period, air is given off by the heating water, and venting can be necessary. If bubbling sounds can be heard from the heat pump, the entire system requires further venting. NOTE! The safety valve (52) also acts as a manual venting valve. Operate it with care, since it opens quickly.

Draining the heating system

The hot water can be drained off through the drain valve (51) using an R15 (1/2") hose coupling. Remove the cover (80) from the valve (51). Screw on the hose coupling and open the valve (51). Open the safety valve (52) to let air into the system.

Draining the water heater

This is how to drain the water heater:

- Disconnect the overflow pipe from the drain connection and connect a hose to a draining pump instead. Where no draining pump is available, the water can be released into the overflow funnel (99).
- Open the drain valve (47).
- Open a hot water tap to let air into the system. If this is not enough, undo the pipe coupling (74) on the hot water side and pull out the pipe.


Note!

At the time of commissioning complete all relevant sections of the Benchmark Checklist enclosed with the product.

Completion of the Benchmark Checklist is a condition of warranty. For full terms and conditions of warranty, please see our website www.nibe.co.uk

Temperature levels

Hot water temperature, anti freeze and periodic increase of the hot water are set using dipswitch (S1) on the circuit board (34). The image below shows the dip switch in the factory setting.



	4	3	2	1
OFF	off	7 days	off	50/53
ON	on	every day	on	57/60

- 1 Hot water temp. with compressor (°C)
- 2 Hot water prioritisation
- 3 Interval for periodic increase
- 4 Periodic increase off/on

Hot water temp.

The compressor starts when the temperature at the compressor sensor drops to 50°. The compressor stops when the temperature reaches 53°. This means that the hot water temperature will be between 50-53 °C. If hotter water is required, the compressor's start and stop temperatures can be increased by seven degrees.

Activate the function by setting switch 1 on the dip switch (S1) to ON.

Periodic increase

F205P has a function for periodic increases of the hot water temperature. The hot water temperature is increased to about 60 °C.

Activate the function by setting switch 4 on the dip switch (S1) to ON and by setting switch, hot water prioritisation (25) to Auto.

Then choose how often the increase is to occur. The factory setting is once every seven days, but by setting switch 3 on the dip switch (S1) to ON the increase occurs once a day.

During periodic increases, the circulation pump is off and heating is produced mostly by the immersion heater only. The energy saving is affected negatively.

Hot water prioritising

In cases where continuous operation of the circulation pump is required, F205P is also equipped with a switch (18) which can be shifted between continuous and automatic operation, i.e. when the control system determines whether the circulation pump is to be in operation or not, see section "Electrical connection" - "Circulation pump control".

Note! If continuous operation is selected, hot water prioritisation does not work. The periodic temperature increase should not be activated.

If hot water prioritisation is activated, all energy from the compressor and immersion heater is used (if 2 on switch is selected) to heat the water. This normally happens when the temperature at the immersion heater sensor (88) drops to 48 °C. The circulation pump starts again when the temperature reaches 51 °C. These temperatures can be reduced two degrees (i.e. 46 respectively 49 °C) to delay prioritisation slightly. This is done by changing the position of switch number 2 on the circuit board (34) to "ON".

F205P has a 3-position switch (25) to select the suitable hot water operation, so-called hot water prioritisation.

The following three positions can be selected:


- Off This means that hot water prioritisation is not activated.
- To Hot water prioritisation is activated.
- Auto Not used. Same function as "On".

Note!

During periodic increase, the immersion heater also connects when position 1 on the switch is selected.

Opening the cover on the distribution box

To lower the front panel, unscrew the two screws at the top of the panel. The panel can then be lowered to the horizontal position (where it rests on stops on either side of the front panel).



Refrigerant system



Work on the refrigerant system must be done by authorised personnel in accordance with the relevant legislation on refrigerants, supplemented by additional requirements for flammable gas, for example, product knowledge as well as service instruction on gas systems with flammable gases.

Note!

Any servicing must be carried out by a competent person.

When replacing a part on the appliance, use only spare parts supplied by NIBE.

Note!

If any electrical connections have been disconnected and reconnected, checks for earth continuity must be tested for with a suitable multimeter.

Note!

After service, complete all relevant sections of the Benchmark Checklist enclosed with the product.

Completion of the Benchmark Checklist is a condition of warranty. For full terms and conditions of warranty, please see our website www.nibe.co.uk

Service actions

See also the sections "Maintenance routines" and "Dealing with malfunctions".

General Inspection

Check the following:

1. Condition of casing.
2. Electrical supply connections.
3. Water connections.
4. Heating system pressure.

Correct any fault before continuing.

Hot water heater

The following components must be inspected:

1. Expansion relief valve. Check correct operation.
2. T&P relief valve. Check for correct operation.
3. Check that discharge pipe is free of any obstructions.
4. Check expansion vessel is fully charged.

Heating system


1. Inspect compressor start and stop temperature. Correct if required.
 2. Inspect the setting of the limiting valve.
 3. Check operation of clock thermostat.
 4. Check flow temperatures, the difference should be between 5-10°
- Adjust flow if required.

Draining the water heater

The siphon principle is used to empty the hot water heater. This can be done either via the drain valve on the incoming cold water pipe or by inserting a hose into the cold water connection.


Electrical circuit diagram

Electrical circuit diagram



5	6	7	8
3	4	5	6
1	2	3	4
WIRING DIAGRAM 1x230V 3kW DC-FAN F205P			
Checked: _____ Design: _____		Sheet: 1 Replaces: _____ Date: _____ Scale: _____	
Drawn: _____ Location: +1		Plant: _____ Date: _____ Scale: _____	
PE.1 -X20 PE.2 PE.3 PE.4		DC Exhaust air -M36	
-R69 Compressor heater		-M16 Circulation pump	
-R1 3x1.0 kW Immersion Heater		-B6 Thermostat	
-E34 Relay board		-RE1, -RE2, -RE3 Relays	
-S1, -S2 Switches		-X1 to -X12 Terminal blocks	
-M16 Circulation pump		-M36 Exhaust air	
-R1 3x1.0 kW Immersion Heater		-B6 Thermostat	
-E34 Relay board		-RE1, -RE2, -RE3 Relays	
-S1, -S2 Switches		-X1 to -X12 Terminal blocks	
-M16 Circulation pump		-M36 Exhaust air	
-R1 3x1.0 kW Immersion Heater		-B6 Thermostat	

Component locations





List of components

- | | |
|--|--|
| 1 Immersion heater - 3,0 kW | 34 Microprocessor board with power pack |
| 3 Resetting, temperature limiter (hidden) | 35 Capacity setting, circulation pump |
| 5 Limiting valve, heating system | 36 Exhaust air fan |
| 6 Thermostat and temperature limiter, immersion heater | 41 Low pressure pressostat |
| 7 Temperature limiter, compressor | 42 Boiler pressure gauge |
| 8 Power switch with mode 0 - 1 - 2 - 3 | 43 Boiler thermometer |
| 9 Feeding terminal and clock thermostat | 44 Shutoff valve, pump and supply heating system |
| 11 Terminal block for fan switch | 47 Safety valve, water heater |
| 16 Circulation pump | 48 Expansion valve |
| 18 Pushbutton switch for circulation pump | 50 Shutoff valve, return line heating system |
| 19 Setting knob for limiting valve | 51 Drain valve, heating system |
| 20 Exhaust air connector | 52 Safety valve, heating system |
| 25 Pushbutton switch for hot water prioritising | 53 Vacuum valve (hidden) |
| 26 Motor protection device for compressor | 58 Tension load stop for feeding conductor |
| 27 Compressor | 59 Tension load stop for room thermostat conductor |
| 28 Working capacitor for compressor | 62 Evaporator |
| 30 Indicator lamp "Compressor running/alarm" | 63 Air filter |
| 31 Indicator lamp "Defrosting on/check filter" | 65 Filter drier |
| 32 Indicator lamp "Immersion heater on" | 66 Type plate |
| 33 High pressure pressostat | 69 Compressor heater |

	Connection	Setting-out dimensions		
		A	B	C
70 Flow line, heating system	Compression ring Ø 22 mm ...	105	465	90
71 Return line, heating system	Compression ring Ø 22 mm ...	130	465	190
73 Cold water connection	Compression ring Ø 22 mm ...	180	465	290
74 Hot water outlet from water heater	Compression ring Ø 22 mm ...	295	465	345
77 Side access panel to valve connections				
78 Filter box (hidden)				
80 Drain connection, heating system	R 15 utv			
82 Room thermostat (accessory)				
84 Ventilation opening				
85 Expansion vessel				
86 Temperature sensor from evaporator				
88 Temperature sensor from immersion heater & hot water prioritising				
90 Ventilation connection for exhaust air	Ø 125 mm	2095	295	160
91 Ventilation connection for vented air	Ø 125 mm	2095	295	485
94 Temperature sensor for working compressor				
95 Overflow pipe, safety valve water heater				
96 Overflow pipe from heating system safety valve				
97 Condensate drain from fan box				
98 Overflow water discharge	PVC-pipe, 32 mm outer diameter			
99 Collecting funnel, waste water				
103 Serial number sign				
104 Temperature and pressure valve				
107 Expansion vessel, tap water	151 Filling valve, heating system cw-side			
108 Tundish from safety valve				
109 Tundish from pressure valve				
148 Pressure reduction valve				
149 Connection for flexible hose to CW-side				
150 Connection for flexible hose to heating-side				


Dimensions

Dimensions and setting-out coordinates




A clear space of 500 mm is needed in front of the heat pump for servicing.

When running pipes in the hatched area to facilitate servicing.




Principle of dimensioning




Enclosed kit

Expansion vessel, tap water
(is delivered separately)




Clock thermostat




Part no. 518 405

Bracket
(is delivered separately)




Earth cable



Part no. 418 172

Accessories


Heightening console
Height: 125 mm



Part no. 089195

Top cabinet

A top cabinet is available as an accessory to conceal the ventilation ducts above the heat pump.



Top cabinet 245 mm. Part no 089 424

Top cabinet 345 mm. Part no 089 426

Top cabinet 385 — 535 mm. Part no 089 428



Technical Data

Height (excl. feet 15-40mm)	mm	2 095
Required ceiling height	mm	2 185
Width	mm	600
Depth	mm	615
Net weight	kg	195
Total volume	litre	240
Volume in double jacket	litre	70
Water heater volume	litre	170
Expansion vessel volume, heating system	litre	12
Expansion vessel volume, tap water	litre	18
Supply voltage	230 V~ 1-phase + N	
Max operating current	A	16.7
Immersion heater power rating	kW	3
Circulation pump power rating	W	45
Exhaust air fan power consumption (DC)	W	25-140
Compressor power rating	W	550
COP*		3.3
Heating capacity*	kW	1.5
Total power input*	kW	0.45
Current*	A	2.3
Protection	IP21	
Break pressure for high pressure pressostat	MPa (bar)	2.45 (24.5)
Break pressure for low pressure pressostat	MPa (bar)	0.15 (1.5)
Maximum pressure in water heater	MPa (bar)	0.6 (6)
Maximum pressure in double jacket vessel	MPa (bar)	0.3 (3)
Design pressure in double jacket volume	MPa (bar)	0.25 (2.5)
Opening pressure T&P valve	MPa (bar)	0.7 (7)
Opening temperature T&P valve	°C	90-95
Refrigerant quantity	g	420
Refrigerant type	R290 (propane)	
Min air flow, exhaust air	m ³ /h	100
Exhaust air temperature range	°C	16-30
Cut-in temperature for compressor (Controlled by a separate sensor)	°C	50 **
Cut-out temperature for compressor	°C	53 **
Cut-in temperature for immersion heater	°C	49 **
Cut-out temperature for immersion heater	°C	52 **
Inlet dry bulb temperature	°C	21
Water outlet temperature	°C	50
Setting area for the limiting valve	°C	38-55
Cut-out temperature, thermostat for immersion heater	°C	70
Cut-out temperature, temperature limiter for immersion heater	°C	88
Cut-out temperature, temperature limiter for compressor	°C	88
Sound power level***	dB(A)	46-50
Sound level in room where installed****	dB(A)	42-46
LW*****	dB(A)	50
LWD suction*****	dB(A)	49
LWD discharge*****	dB(A)	54
Part no.		089 890

Clock thermostat

Sensing element		NTC
Accuracy	K	±0,5
Set-point range:	°C	5-35
Operating Temperature:	°C	0~45
Operating Humidity:		5~90%RH (non-condensing)
Power supply:		AC 85~260V, 50/60Hz
Switch current rating	A	Resistive: 2
	A	Inductive: 1
Rated power	W	<1
Wirings		Screw-in terminals, each terminal capable of accepting 2 x 1,5 mm ² or 1 x 2,5 mm ² wires
Housing		ABS+PC Flame Retardant
Dimensions: (WxHxD)	mm	86x86x13
Hole pitch	mm	60 c/c
Protection Class:		IP30
Display		LCD

* COP and heating capacity according to EN 14511. Rating condition: Air flow, exhaust air 150 m³/h. Inlet dry bulb temperature 20 °C. Inlet wet bulb temperature 12 °C. Water Inlet temperature 40 °C. Water outlet temperature 45 °C.

** Concerns settings on delivery

*** A-weighted sound power level (LWA). The value varies with the selected fan curve.

**** A-weighted sound pressure level (LpA). The value varies with the damping capacity of the room. These values apply with a damping of 4 dB.

***** Sound power level according to EN 12102. Rating condition: Air flow, exhaust air 300 m³/h. Inlet dry bulb temperature 21 °C. Water outlet temperature 50 °C.

MAINS PRESSURE HOT WATER STORAGE SYSTEM COMMISSIONING CHECKLIST

This Commissioning Checklist is to be completed in full by the competent person who commissioned the storage system as a means of demonstrating compliance with the appropriate Building Regulations and then handed to the customer to keep for future reference.

Failure to install and commission this equipment to the manufacturer's instructions may invalidate the warranty but does not affect statutory rights.

Customer Name _____ Telephone Number _____
Address _____
Cylinder Make and Model _____
Cylinder Serial Number _____
Commissioned by (print name) _____ Registered Operative ID Number _____
Company Name _____ Telephone Number _____
Company Address _____
Commissioning Date _____

To be completed by the customer on receipt of a Building Regulations Compliance Certificate*:

Building Regulations Notification Number (if applicable) _____

ALL SYSTEMS PRIMARY SETTINGS (indirect heating only)

Is the primary circuit a sealed or open vented system? Sealed Open
What is the maximum primary flow temperature? _____ °C

ALL SYSTEMS

What is the incoming static cold water pressure at the inlet to the system? _____ bar
Has a strainer been cleaned of installation debris (if fitted)? Yes No
Is the installation in a hard water area (above 200ppm)? Yes No
If yes, has a water scale reducer been fitted? Yes No
What type of scale reducer has been fitted? _____
What is the hot water thermostat set temperature? _____ °C
What is the maximum hot water flow rate at set thermostat temperature (measured at high flow outlet)? _____ l/min
Time and temperature controls have been fitted in compliance with Part L of the Building Regulations? Yes
Type of control system (if applicable) Y Plan S Plan Other
Is the cylinder solar (or other renewable) compatible? Yes No
What is the hot water temperature at the nearest outlet? _____ °C
All appropriate pipes have been insulated up to 1 metre or the point where they become concealed Yes

UNVENTED SYSTEMS ONLY

Where is the pressure reducing valve situated (if fitted)? _____
What is the pressure reducing valve setting? _____ bar
Has a combined temperature and pressure relief valve and expansion valve been fitted and discharge tested? Yes No
The tundish and discharge pipework have been connected and terminated to Part G of the Building Regulations Yes
Are all energy sources fitted with a cut out device? Yes No
Has the expansion vessel or internal air space been checked? Yes No

THERMAL STORES ONLY

What store temperature is achievable? _____ °C
What is the maximum hot water temperature? _____ °C

ALL INSTALLATIONS

The hot water system complies with the appropriate Building Regulations Yes
The system has been installed and commissioned in accordance with the manufacturer's instructions Yes
The system controls have been demonstrated to and understood by the customer Yes
The manufacturer's literature, including Benchmark Checklist and Service Record, has been explained and left with the customer Yes

Commissioning Engineer's Signature _____

Customer's Signature _____
(To confirm satisfactory demonstration and receipt of manufacturer's literature)

*All installations in England and Wales must be notified to Local Authority Building Control (LABC) either directly or through a Competent Persons Scheme. A Building Regulations Compliance Certificate will then be issued to the customer.



Service Record

It is recommended that your heating system is serviced regularly and that the appropriate Service Interval Record is completed.

Service Provider

Before completing the appropriate Service Interval Record below, please ensure you have carried out the service as described in the manufacturer's instructions.

Always use the manufacturer's specified spare part when replacing controls.

Service 1

Date: _____

Engineer Name: _____

Company Name: _____

Telephone No. _____

Operative ID No. _____

Comments: _____

Signature: _____

Service 2

Date: _____

Engineer Name: _____

Company Name: _____

Telephone No. _____

Operative ID No. _____

Comments: _____

Signature: _____

Service 3

Date: _____

Engineer Name: _____

Company Name: _____

Telephone No. _____

Operative ID No. _____

Comments: _____

Signature: _____

Service 4

Date: _____

Engineer Name: _____

Company Name: _____

Telephone No. _____

Operative ID No. _____

Comments: _____

Signature: _____

Service 5

Date: _____

Engineer Name: _____

Company Name: _____

Telephone No. _____

Operative ID No. _____

Comments: _____

Signature: _____

Service 6

Date: _____

Engineer Name: _____

Company Name: _____

Telephone No. _____

Operative ID No. _____

Comments: _____

Signature: _____

Service 7

Date: _____

Engineer Name: _____

Company Name: _____

Telephone No. _____

Operative ID No. _____

Comments: _____

Signature: _____

Service 8

Date: _____

Engineer Name: _____

Company Name: _____

Telephone No. _____

Operative ID No. _____

Comments: _____

Signature: _____

Service 9

Date: _____

Engineer Name: _____

Company Name: _____

Telephone No. _____

Operative ID No. _____

Comments: _____

Signature: _____

Service 10

Date: _____

Engineer Name: _____

Company Name: _____

Telephone No. _____

Operative ID No. _____

Comments: _____

Signature: _____

